

TOXIRAE - Bump procedures

1. Turn on ToxiRAE after 60 sec countdown if you see "**BUMP**" flashing in the upper left corner of the screen go to next step.
2. Press the "On" button 5 times (you should see "**BUMP** and **SPAN**" flashing on the left of the screen. You should also see "**50?**" On the right side of the screen.
3. Hook up the gas to the right sensor at the top of the ToxiRAE and turn on.
4. Press and release the "**y/+**" button.
5. The bump is complete when you see "**OK**" flashing in place of the "**BUMP** and **SPAN**" should only take about 5 to 7 sec.
6. Turn off gas and unhook the hose the ToxiRAE is ready for use.